

# Corrado Oil/Volt Gauge Installation



Remove the screw at the back of the cigarette tray housing.



Let the housing drop downward to expose the light bulb holder on the top. To remove the bulb holder from the housing, press down on the bulb holder.



Angle the bulb holder up and out of the housing. Remove the housing.



Remove the 2 screws indicated by the arrows. Disconnect the harness at the back of the gauge and pull out the gauge cluster.



Remove the 4 screws at the back of the gauge.



Pull the back cover off, then pull out the gauge cluster.



Make a note of the needle positions. Remove them by gently pulling straight up. Peel the original gauge face off. Place the new face on. It should stick with the glue that was left behind from the original face. Put the needles back on.



Put the cluster back into the housing. Put back the back cover. Put the cluster back into the dash. Run the harness from the inverter down to the gauge and plug it into the gauge harness. Reinstall the gauge in reverse order.



Turn the ignition on and the lights will light up. If it doesn't see the FAQ to trouble shoot.

## Online instructions:

The latest updated information can be downloaded from <http://www.dubdesignindustries.com/installation/gaugesinstall.pdf>, <http://www.dubdesignindustries.com/installation/oilvolt.pdf>, <http://www.dubdesignindustries.com/installation/gaugefaq.pdf>

**Disclaimer:** By installing the gauges, you are acknowledging that you are taking full responsibility to any possible damages that may occur to your car in part or in whole. You acknowledge that Dub Design Industries is not held liable to any possible damages.